

## Parts list and mounting instruction

**Best No.:** 7811 HO KH SWT 400/600

**Article:** Side Case Holder for Givi/Kappa Cruiser Cases

**1 pair of Side Case Holder**

**2 x 7777 Lockkit for Givi/Kappa Cruiser Case**

1 x Parts list and mounting instruction

2 x Label Max. load max. 5 kg

**Mounting parts front on top:**

2 x assembly strap

Assembly strap on motorcycle:

Use original screw

Side Case Holder on assembly strap:

2 x Hexagon socket button head screw

2 x Washer

ISO 7380

M 8 x 16 mm

DIN 125

M 8

**Mounting parts back:**

1 x assembly holder large

Assembly holder on Handhold:

4 x Tapping screw, hexagon head

4 x Washer

DIN 7976 Typ C

4.8 x 19 mm

DIN 9021

M 5

Side Case Holder to assembly holder:

2 x Hexagon socket button head screw

2 x Washer

2 x Self locking hexagon nut

ISO 7380

M 8 x 16 mm

DIN 125

M 8

DIN 985

M 8

**Mounting parts below left:**

1 x Counterstrap with thread

1 x Hexagon Screw

1 x Washer DIN 125 M 8

DIN 933

M 8 x 20 mm

**Mounting parts below right:**

1 x Hexagon Screw

2 x Washer

1 x Self locking hexagon nut

DIN 931

M 8 x 60 mm

DIN 125

M 8

DIN 985

M 8



Picture 7811

Datum/Name	Erstellt	Geändert	Geprüft Entwicklung	Geprüft Verkauf	Freigabe
	2012-04-12 PK				



Picture 7811\_M

## Mounting instruction:

- Remove the original Handhold (4 screws).
- Remove the plastic cover under the Handhold.
- Mount the Assembly holders large with the listed mounting parts under the Handhold.
- Lay Assembly straps right and left in the openings.
- Mount the Original Handhold again.
- The original plastic cover cannot be mounted again.
- Mount the Side Case Holder with the listed mounting parts, aim and firmly screw together.
- Torques for bolts and nuts like from the manufacturer given (if not given: M 4: 3 nm, M 5: 5.9 nm, M 6: 10 nm, M 8: 25 nm, M 10: 49 nm, M 12: 85 nm).
- Mount the screws if necessary with liquid screw protection.

### Care and servicing:

To reach a long live span of our chromium-plated articles they should be cleaned regularly and be treated with customary chrome care means.

With powder coated articles a regular cleaning is important. Damages (e.g. by rockfall) can be mended with colour.

By both versions we recommend about the winter the spraying or rubbing with corrosion protection oil or silicone.

All fixing bolts must be checked at regular intervals (max. 6 months).

**We wish you a lot of joy and accident-free journey with our motorcycle accessories.**